

NORDIC D'LUXX[®]



**BRUGERMANUAL
USERMANUAL**

NORDIC D'LUXX FLOWERPOT



DANSK

Indhold	Side 2
Velkommen	Side 3
Advarsler	Side 3
Vigtige sikkerhedsinstruktioner	Side 4
Garanti og reklamation	Side 4
Generelle specifikationer	Side 4
Produktspecifikationer	Side 5-7
Brugervejledning	Side 7-10

ENGLISH

Content page	Page 2
Welcome	Page 11
Warnings	Page 11
Warranty and complaint	Page 11-12
Important safety instructions	Page 12
General specifications	Page 12
Product specifications	Page 12-15
User guide	Page 15-18

VELKOMMEN

Du har gjort et fremragende valg med købet af NORDIC D'LUXX flowerpot. Produktet er fremstillet efter de højeste standarder for ydeevne, design og kvalitet. Vi håber, at du får stor glæde af produktet.

Design by 365° NORTH

De smukke danskdesignede NORDIC D'LUXX Flowerpots har nærmest uanede muligheder for anvendelse, både indendørs og udendørs. Flowerpot findes i tre størrelse, M, L og XL og hver størrelse produceres med eller uden trådløs højttaler.

NORDIC D'LUXX Flowerpot har indbygget lys, og er oplagt til brug på terrassen, altanen eller overalt indendørs. Du kan indstille lysstyrken, de mange farvetoner eller bruge de forprogrammerede lys indstillinger i appen. Ligeledes kan tænd /sluk tidspunkter indstilles via Timer-funktionen.

Både lys og lyd i Flowerpot styres ganske enkelt via en APP på din smartphone, uanset IOS eller Android.

Produktet har indbygget lithiumbatteri og kan derved anvendes trådløst og på farten. Som navnet på produktet indikerer, kan du naturligvis også bruge din Flowerpot som blomsterkrukke, eller fylde den med isternen og anvende den som køler.* Mulighederne er som sagt uendelige.

ADVARSLER

- Dette apparat er til husholdningsbrug, indendørs og udendørsbrug.
- Flowerpot er IP65 godkendt og kan bruges udendørs i henhold til IP65 specifikationerne.
- Adapteren er IP44 godkendt og kan anvendes ifølge IP44 specifikationer. Hvis adapter bruges udendørs sørg da for at beskytte mod vand efter IP44 standard.
- Du må ikke bruge eller opbevare enheden i høj temperatur – se generelle specifikationer.
- Garantien for dette produkt er ugyldig, hvis produktet er blevet manipuleret, repareret eller modificeret på nogen måde.
- Undgå at lytte til musik ved høj lydstyrke i længere tid, da det kan forårsage skade på dine ører.
- Hvis Flowerpot anvendes uden at stikket fra adapteren er isat, skal du huske at sætte medfølgende gummistik i laderindgangen for at forhindre vandskader.
- Vi anbefaler, at produktet opbevares inde om vinteren.
- Silikoneprop under basen skal være isat for at bevare vandtæthed.

*Kun ved flowerpot str. M og L

VIGTIGE SIKKERHEDSINSTRUKTIONER

- Læs, gem og følg alle instruktioner.
- Brug ikke produktet til andre formål end det tilsigtede anvendelsesformål.
- Oplad ikke apparatet med andre strømforsyninger end den medfølgende adapter, da det kan medføre skader på enheden.
- Stop med at bruge produktet med det samme, hvis du oplever overophedning, mærkelige lyde eller nedsat ydeevne under brug.
- Undgå at tabe enheden på gulvet / jorden, da enheden kan blive beskadiget.
- Brug ikke kraftige rengøringsmidler til at rengøre enheden. Brug en hårdt opvredet klud til aftørring af produktet.
- Anbring ikke enheden i lokaler med høje temperaturer, udsæt ikke enheden for åben ild, da det kan resultere i en eksplosion.

GARANTI OG REKLAMATION

I tilfælde af at produktet er defekt, så kontakt os på info@nordicdLUXX.dk for øjeblikkelig hjælp. Defekte produkter inden for garantiperioden vil blive repareret eller udskiftet gratis, forudsat at du kan dokumentere købet. Garantiperiode BtB er 6 måneder og på detail 2 år. Vær dog opmærksom på, at garantien bliver ugyldig, hvis produktet viser sig at have været bevidst beskadiget, misbrugt eller adskilt.

Da produktet er delvist håndlavet kan små variationer forekomme i overfladestruktur og farve, dette er normalt og betragtes ikke som en produktfejl. Samme gælder for læderremmen, hvor variationer i farve og overflade kan forekomme, dette er normalt og betragtes ikke som en produktfejl. Når lyset er tændt er skygger fra højttaleren inde i enheden synlige i selve krukken. Dette er ikke en produktfejl.

GENERELLE SPECIFIKATIONER:

- Indendørs og udendørs brug
- LED multifarve RGB W lys 20.000 timers levetid
- Genopladeligt lithium batteri
- Adapter til opladning
- APP kontrol til smart phone IOS eller Android
- Langtidsholdbar brudsikker LLDPE plast
- Vejrbestandig
- UV-bestandig
- Driftstemperatur - 20 ° C til 40 ° C
- Vandtæt IP65, adapter IP44
- Læder bærehåndtag
- Transmissionsafstand op til 10 meter afhængig af miljø

PRODUKTSPECIFIKATIONER:

Flowerpot M med lys

- Diameter 20 cm
- Højde 16 cm
- Vægt 1 kg
- Adapter DC 5V/ 1A
- Bluetooth V 4.0
- Genopladeligt 1800 mAh Lithium batteri
- Lystiden ved 50% lysstyrke og fuldt opladet batteri ca. 15 timer
100% lysstyrke ca. 7 timer
- Opladning af batteri 2 timer
- Fødevarekontakt godkendt i henhold til EC 1935/2004 og 10/2011 
- LED 20 x 1 W (RGB W)

Flowerpot M med lys og højttaler

- Diameter 20 cm
- Højde 16 cm
- Vægt 1,5 kg
- Adapter DC 5V/1A
- Vandtæt højttaler 5W
- Frekvens: 20 Hz – 20000 Hz
- Sensitivity: -90dbm
- Signal to noise ratio: ≥75dB
- Forstærker 5W
- Bluetooth V 4.0
- Genopladeligt 1800 mAh Lithium batteri
- Lystiden ved 50% lysstyrke og fuldt opladet batteri ca. 15 timer
100% lysstyrke ca. 7 timer
- Musik spilletid ved 50% volumen og fuldt opladet batteri 4,5 time
100% volumen ca. 2,5 time
- Lys og musik spille / lys tid ved 100% lysstyrke / 100 % musik volumen og fuldt opladet batteri ca. 2 timer
- Opladning af batteri 2 timer
- Fødevarekontakt godkendt i henhold til EC 1935/2004 og 10/2011 
- LED 16 x 0,8 W (RGB W)

Flowerpot L med lys

- Diameter 34 cm
- Højde 41 cm
- Vægt 3,7 kg
- Adapter DC 5V/1A
- Bluetooth V 4.0
- Genopladeligt 3000 mAh Lithium batteri
- Lystiden ved 50% lysstyrke og fuldt opladet batteri ca. 14 timer
100% lysstyrke ca. 7 timer
- Opladning af batteri ca. 3 timer
- Fødevarekontakt godkendt i henhold til EC 1935/2004 og 10/2011 
- LED 20 x 1 W (RGB W)
- Integreret gevind til montering af jordspyd. Brug jordspyd med M8 gevind

Flowerpot L med lys og højttaler

- Diameter 34 cm
- Højde 41 cm
- Vægt 4,7 kg
- Adapter DC 5V/2A
- Vandtæt højttaler 15W
- Frekvens: 20 Hz – 20000 Hz
- Sensitivity: -90dbm
- Signal to noise ratio: ≥ 75 dB
- Forstærker 14 W
- Bluetooth V 4.0
- Genopladeligt 6000 mAh Lithium batteri
- Lystiden ved 50% lysstyrke og fuldt opladet batteri ca. 14 timer
- 100% lysstyrke ca. 7 timer
- Musik spilletid ved 50% volumen og fuldt opladet batteri 6 timer
- 100% volumen ca. 3 timer
- Lys og musik spille/lys tid ved 100% lysstyrke / 100% musik volumen og fuldt opladet batteri ca. 2 timer
- Opladning af batteri 2 timer
- Fødevarekontakt godkendt i henhold til EC 1935/2004 og 10/2011 
- LED 20 x 1 W (RGB W)
- Integreret gevind til montering af jordspyd. Brug jordspyd med M8 gevind

Flowerpot XL med lys

- Diameter 44 cm
- Højde 64 cm
- Vægt 4,5 kg
- Adapter DC 5V/1A
- Bluetooth V 4.0
- Genopladeligt 3000 mAh Lithium batteri
- Lystiden ved 50% lysstyrke og fuldt opladet batteri ca. 12 timer.
- 100% lysstyrke ca. 6 timer
- Opladning af batteri ca. 3 timer
- LED 40 x 2 W (RGB W)
- Integreret vand dræn til brug udendørs
- Integreret gevind til montering af jordspyd. Brug jordspyd med M8 gevind.

Flowerpot XL med lys og højttaler

- Diameter 44 cm
- Højde 64 cm
- Vægt 5,5 kg
- Adapter DC 5V/2A
- Vandtæt højttaler 15W
- Frekvens: 20 Hz – 20000 Hz
- Sensitivity: -90dbm
- Signal to noise ratio: ≥ 75 dB
- Forstærker 14 W
- Bluetooth V 4.0

- Genopladeligt 6000 mAh Lithium batteri
- Lystiden ved 50% lysstyrke og fuldt opladet batteri ca. 12 timer.
100% lysstyrke ca. 6 timer
- Musik spilletid ved 50% volumen og fuldt opladet batteri 5 timer
100 % volumen ca. 2,5 timer
- Lys og musik spille / lys tid ved 100% lysstyrke /
100% musik volumen og fuldt opladet batteri ca. 2 timer
- Opladning af batteri 2 timer
- LED 40 x 2 W (RGB W)
- Integreret vanddræn til brug udendørs
- Integreret gevind til montering af jordspyd. Brug jordspyd med M8 gevind



BRUGERVEJLEDNING

Før brug, skal du huske at stramme de rustfri skuer til læderremmen, da de kan være løse efter transport.

Vær generelt tålmodig ved forbindelse via app'en til Flowerpots. Ved forbindelse afsøger enheden alle åbne forbindelser i området og det kan tage op til nogle minutter.

1. Download NORDIC D'LUX app fra Apple Store (IOS) eller Google Play (Android) afhængig af din smartphone og installer appen 
2. Tilslut adapteren og oplad i 12 timer - vigtigt for batteriets levetid.
Nu er du klar til at anvende din NORDIC D'LUX flowerpot
3. Tryk først på ON / OFF knappen under bunden og hold knappen inde i 10 sekunder, indtil lyset begynder at blinke og stopper igen. Nu er produktet nulstillet og klar til, at du kan lave din egen NORDIC D'LUX konto

4. Login og opsæt din NORDIC D'LUXX konto.
Tilføj navn efter eget valg, mellem 1-16 cifre/ tegn.
Indtast kontonavn og tryk Log on.
Bekræft valg af kontonavn ved at indtaste kontonavn igen. Tryk OK.
5. Tilslutning til Flowerpot: Sørg for at Bluetooth-forbindelsen på telefonen er sluttet til.
Gå til My device siden. Tryk +
Tryk på ikonet Light, hvorefter du kommer til siden New device. Systemet søger nu automatisk efter tilgængelige Flowerpots.
6. Når enhedskoden "eksempel 0000300100038315" vises på skærmen, skal du trykke på ikonet for at oprette forbindelse. Systemet vil nu automatisk oprette forbindelse mellem din konto og den valgte Flowerpot.
7. Gå tilbage til My device siden ved at trykke midt på skærmen. Opdater ved at trække fingeren ned på skærmen, og slip.
Du vil nu se et orange ikon. Orange betyder, at du er tilsluttet. Gråt ikon betyder, at du ikke er tilsluttet.

Enhedskoden vil også være synlig under Devise management siden. Denne finder du ved at trykke på "Settings" i nederste højre hjørne. Alle dine tilgængelige enheder vil blive vist her.

For at spare strøm vil enheden afbryde, hvis den ikke bruges i 1 minut. Ikonet for enheden bliver gråt og går i dvaletilstand. Tilslut ved at trække fingeren ned på skærmen, og slippe. Ikonet bliver orange, når der igen er oprettet forbindelse. Hvis du har problemer med at genforbinde luk da appen og genstart den.

8. For at anvende lysstyringsfunktionen tryk da på ikonet til den enhed, du ønsker at forbinde til.

For at tænde for lyset tryk på tænd / sluk-ikonet 

Som standardfarve er Flowerpot sat op til varm gul. For at aktivere tryk 

Andre forudindstillede farver kan aktiveres ved at trykke på farveikonet



Eller tryk på en farve i farvehjulet for at aktivere den farve, du foretrækker

Brug skyderen  til at indstille lysintensiteten

LUXXLight menuen har følgende forudindstillede funktioner:

- **Spa Light.** Spa lysterapi. Tryk på ikonet Spa light og det indstillede lys program starter. Lyset skifter mellem forskellige farver og lysintensitet ændres op og ned i et forprogrammeret mønster.
- **Sunrise.** Tryk på Sunrise ikonet og det indstillede lysprogram starter. Lysintensitet starter fra laveste intensitet og inden for 30 minutter stiger det til maksimum lysintensitet.

- **Breathing.** Tryk på ikonet Breathing og det indstillede lysprogram starter. Skifter mellem laveste lys intensitet og maksimal intensitet.
- **Random.** Tryk på Random ikonet og det indstillede lysprogram starter. Farver og intensitet skifter tilfældigt.
- **Timer.** I Timer-funktionen kan du programmere On/Off tid for alle lys funktion såsom Spa Light, Sunrise, Breathing, Random eller bare hvilken som helst farve og intensitet, du foretrækker.

For at programmere timerfunktionen tryk på Timer ikonet og tryk + Indstil ønskede tidspunkt. Vælg om kun én gang eller hver ugedag. Tryk Set up for at komme til Lys meny Vælg farve, intensitet eller en af de forudindstillede programmer og tryk på Done. Du vil nu igen se den tid, du har indstillet. Tryk på Done. I menuen Timer vises nu On tid. For at indtaste Off tid trykkes på + Indtast Off tid, og tryk på Set up. I menuen Set up skal du trykke på Off ikon (Ikon bliver grå når i slukket tilstand) Tryk Done Du vil nu igen se den tid, du har indstillet. Tryk på Done. I menuen Timer vises nu Off tid.

Maksimalt 5 timer programmeringer.

9. Højttaler-funktion

Hvis din Flowerpot har højttalerfunktion, kan du aktivere højttaleren ved at trykke på ikonet Afspil. Du hører en lyd fra din Flowerpot, når højttaleren er aktiveret.



Ikonet afspil aktiverer den trådløse funktion i Flowerpot, og du kan nu gå til Bluetooth indstillinger i din telefon, hvor du vil finde LUXX højttaler i de anførte tilgængelige forbindelser.

Tryk på LUXX højttaler for at forbinde. Når forbindelsen er oprettet programmeres den automatisk ind i Flowerpot og telefon, og du behøver ikke at gøre dette igen, medmindre du afbryder forbindelsen. For at genoprette forbindelse udføres ovenstående igen.

Funktionen af ikonet Play er at aktivere den trådløse enhed i Flowerpot. Den trådløse enhed bruger meget strøm, så husk at afbryde højttaleren efter brug. Gør det ved at trykke på ikonet II. Dette deaktiverer den trådløse funktion i Flowerpot.

Efter tilslutning af din telefon til Flowerpot kan du afspille musik fra en af dine musikklender eller direkte fra din telefon.

Hvis højttaleren er aktiveret kan andre brugere uden NORDIC D'LUXX appen oprette forbindelse til højttaleren blot ved at gå til deres Bluetooth-indstillinger i deres telefon og oprette forbindelse til højttaleren. En aktiv bruger skal kobles fra højttaleren, for at ny bruger kan oprette forbindelse.

Du kan også oprette forbindelse til højttaleren ved at trykke på On knappen i bunden af Flowerpot. Dette aktiverer Bluetooth chippen i Flowerpot, og du kan nu oprette forbindelse via Bluetooth indstillingerne i telefonen.

10. Navngivning af Flowerpot. Du kan navngive dine enheder i menuen. Tryk på tandhjulet øverst til højre. Tryk på "Name" og skriv det navn du ønsker enheden skal hedde.
11. Du kan lave dine egne lysgrupper med to eller flere enheder i menuen under My device. Tryk på + ikonet og herefter Light group. Nu er der oprettet en ny gruppe under my device som hedder "New group". Tryk på ikonet og herefter på tandhjulet øverst til højre. Tryk på "Lights" og vælg de enheder der skal være tilknyttet gruppen. Herefter styres de valgte enheder via gruppen samlet.
12. For at Logge af, gå da til Settings.
Tryk på Quit. Systemet vil gemme kontonavn og logge af.

Erase password and quit. Systemet vil slette den indstillede LUXX konto og logge af.
13. Har du glemt dit kontonavn, slet da konto og start forfra.
Tryk og hold i 10 sekunder på tænd / sluk knappen under bunden af Flowerpot. Dette sletter alle konti, og du kan nu oprette en ny konto til enheden ved at starte fra punkt 5 i manualen.
14. Problemløsning.
Hvis enheden ikke fungerer korrekt, enten efter installation, normal brug, eller på anden måde tryk og hold i 10 sekunder på tænd / sluk knappen under bunden af Flowerpot. Dermed slettes forbindelsen fra enheden til en konto, og du kan nu oprette en ny konto til enheden eller genoprette forbindelsen til en konto ved at starte fra punkt 5 i manualen.
- VIGTIGT!** Hvis batteriet er løbet helt tør for strøm, skal du oplade batteriet før brug, som angivet i det følgende, for ikke at nedsætte batteriets levetid.
- | | | |
|------------------------|-----------------|-----------------------|
| Flowerpot størrelse M | med lys 2 timer | med højttaler 2 timer |
| Flowerpot størrelse L | med lys 3 timer | med højttaler 6 timer |
| Flowerpot størrelse XL | med lys 3 timer | med højttaler 6 timer |
15. For at slette en enhed fra en konto gå til Settings, og tryk på Devise management. Find den enhed du vil slette fra kontoen og slide til venstre. Tryk Delete.

WELCOME

You have made an excellent choice with the purchase of this quality NORDIC D'LUXX Flowerpot. The product has been manufactured to the highest standards of performance, design and quality. We hope you will enjoy the product.

Design by 365° NORTH

The beautiful Danish designed NORDIC D'LUXX Flowerpots have almost unlimited usage possibilities, both indoor and outdoor. Flowerpot is supplied in three sizes, M, L and XL and each size is produced with or without wireless loudspeaker.

NORDIC D'LUXX Flowerpot has built in light and is the obvious choice to be used on the terrace, balcony or everywhere indoor. You can adjust the light and color tones or use the preprogrammed light settings in the APP. Further on/off timing can be set by using the timer-function.

Both light and sound in Flowerpot are controlled very simple by an APP on your smartphone, no matter IOS or Android.

Flowerpot has built in lithium batteries and can be used both wireless and on the move. As the product name indicates, you can of course use your Flowerpot as a flowerpot, or fill it up with ice cubes and use it as a cooler.* Possibilities are endless.

*For flowerpot size M and L only.

WARNINGS

- This appliance is for household, indoor and outdoor use only
- The Flowerpot is IP65 approved and can be used outdoor according to IP65 specifications
- The adapter is IP44 approved and can be used according to IP44 specifications
If used outdoor be sure to protect against water according to IP44 standard
- Please do not use or store the unit in high temperature or hazardous location.
See the general specification
- Please do not submerge the unit into water, as this will ruin the product
- The unit comes with a rechargeable battery, so please do not throw or put it in a fire to avoid explosion
- The warranty for this product is invalid if the product has been tampered, repaired or modified in any way
- Do not listen to music in high volume for long time as it may cause damage to your ears
- If Flowerpot is used without the jack from adapter inserted, remember to insert the included rubber plug into the Charger input to prevent water damage
- We recommend that the Flowerpot is stored inside during winter time
- Silicone plug under base must be in place in order to keep water out

WARRANTY AND COMPLAINT

In the event that the purchase you have made is faulty, please contact us on

info@nordicdLUXX.dk for immediate assistance. Faulty product claims made within the warranty period will be repaired or replaced free of charge provided that you have satisfactory proof of purchase. Warranty period B2B 6 months, retail 2 years. However, be aware that the warranty will become null and void if the product is found to have been deliberately damaged, misused or disassembled. As the Flowerpot is partly handmade small variations might occur in the surface structure and colour, this is normal and is not considered as a product failure. As for the leather strap small variations in colour and surface may occur, this is normal and is not considered as a product failure. When the light is on, shadows from inside of the speaker are visible. This is not a product failure.

IMPORTANT SAFETY INSTRUCTIONS

- Read, keep and follow all instructions
- Do not use the product for any purpose other than its intended use
- Do not charge the unit with other unsuitable AC/DC power adaptor, it may cause damage to the unit
- Stop using the unit and switch of the unit immediately, if you find any overheating situation, strange noise and strange working performance during use
- Do not drop the unit on floor / ground, as the unit could be damaged and broken
- Do not use abrasive cleaning solvents to clean the unit. Use a damp cloth for wiping the product
- Do not place the unit in high temperature, as it will result in an explosion

GENERAL SPECIFICATIONS:

- Indoor and outdoor use
- LED multicolour RGBW light 20.000 Hours lifetime
- Rechargeable Lithium battery
- Adapter for charging
- APP control for smart phone IOS or Android
- Long lasting fracture resistant LLDPE plastic
- Weather resistant
- UV resistant
- Operating temperature – 20 °C to 40 °C
- Water resistant IP65, adapter IP44
- Leather carry handle
- Transmission distance up to 30 meter depending on environment

PRODUCT SPECIFICATIONS:

Flowerpot M with light

- Diameter 20 cm
- Height 16 cm
- Weight 1 kg
- Adapter DC 5V/1A
- Bluetooth V 4.0
- Rechargeable 1800 mAh Lithium battery
- Light time at 50% brightness on full charged battery app 15 hours

- 100% brightness app 7 hours
- Charging time up to 2 hours
- Food contact approved acc. to EC 1935/2004 and 10/2011 
- LED 20 x 1 W (RGB W)

Flowerpot M with light and speaker

- Diameter 20 cm
- Height 16 cm
- Weight 1,5 kg
- Adapter DC 5V/1A
- Waterproof speaker 5W
- Frequency: 20 Hz – 20000 Hz
- Sensitivity: -90dbm
- Signal to noise ratio: ≥ 75 dB
- Amplifier 5W
- Bluetooth V 4.0
- Rechargeable 1800 mAh Lithium battery
- Light time at 50% brightness on full charged battery app 15 hours.
100% brightness app 7 hours
- Music playing time at 50% volume on full charged battery app 4,5 hours.
100% volume app 2,5 hours
- Light and music playing / light time at 100 % brightness/ 100% volume
on full charged battery app 2 hours
- Charging time up to 2 hours
- Food contact approved acc. to EC 1935/2004 and 10/2011 
- LED 16 x 0,8 W (RGB W)

Flowerpot L with light

- Diameter 34 cm
- Height 41 cm
- Weight 3.7 kgs
- Adapter DC 5V/1A
- Bluetooth V 4.0
- Rechargeable 3000 mAh Lithium battery
- Light time at 50% brightness on full charged battery app 14 hours.
100% brightness app 7 hours
- Charging time up to 3 hours
- Food contact approved acc. to EC 1935/2004 and 10/2011 
- LED 30 x 1,5 W (RGB W)
- Ground spike possibility. Use ground spike with thread M8

Flowerpot L with light and speaker

- Diameter 34 cm
- Height 41 cm
- Weight 4.7 kgs
- Adapter DC 5V/2A
- Waterproof speaker 15W

- Frequency: 20 Hz – 20000 Hz
- Sensitivity: -90dbm
- Signal to noise ratio: ≥ 75 dB
- Amplifier 14 W
- Bluetooth V 4.0
- Rechargeable 6000 mAh Lithium battery
- Light time at 50% brightness on full charged battery app 14 hours.
100% brightness app 7 hours
- Music playing time at 50% volume on full charged battery app 6 hours.
100% volume app 3 hours
- Light and music playing / light time at 100% brightness/ 100% volume
on full charged battery app 2,5 hours
- Charging time up to 6 hours
- Food contact approved acc. to EC 1935/2004 and 10/2011 
- LED 30 x 1,5 W (RGB W)
- Ground spike possibility. Use ground spike with thread M8

Flowerpot XL with light

- Diameter 44 cm
- Height 64 cm
- Weight 4.5 kgs
- Adapter DC 5V/1A
- Bluetooth V 4.0
- Rechargeable 3000 mAh Lithium battery
- Light time at 50 % brightness on full charged battery app 12 hours.
100% brightness app 6 hours
- Charging time up to 3 hours
- LED 40 x 2 W (RGB W)
- Water drain for outdoor use
- Ground spike possibility. Use ground spike with thread M8

Flowerpot XL with light and speaker

- Diameter 44 cm
- Height 64 cm
- Weight 5.5 kgs
- Adapter DC 5V/2A
- Waterproof speaker 15W
- Frequency: 20 Hz – 20000 Hz
- Sensitivity: -90dbm
- Signal to noise ratio: ≥ 75 dB
- Amplifier 14 W
- Bluetooth V 4.0
- Rechargeable 6000 mAh Lithium battery
- Light time at 50% brightness on full charged battery app 12 hours.
100% brightness app 6 hours
- Music playing time at 50% volume on full charged battery app 5 hours.
100% volume app 2,5 hours
- Light and music playing / light time at 100% brightness/ 100% volume

- on full charged battery app 2 hours
- Charging time up to 6 hours
- LED 40 x 2 W (RGB W)
- Water drain for outdoor use
- Ground spike possibility. Use ground spike with thread M8



USER GUIDE

Before use, please remember to tighten the stainless screws for the leather strap, as they can be loose after transport.

Please show patience when connecting through the app to the Flowerpot. For connection, the device search for all open connections in the area. This may take up to a few minutes.

1. Download the NORDIC D'LUXX app from Apple Store (IOS) or Google Play (Android) depending on your smart phone solution and install the app. 
2. Plug in the adaptor and charge over 12 hours. It is important for the lifetime of the battery. Now you are ready to start getting to know your NORDIC D'LUXX Flowerpot.
3. First press and hold for 10 seconds the ON/OFF key below the base until the light starts blinking and stops again. Now the Flowerpot is reset and ready for you to make your own and private NORDIC D'LUXX set up.
4. Login and set up of your NORDIC D'LUXX account. Add name by your own choice, use 1- 16 digits / characters for your account name.

Enter account name of your choice. Press Log on
Confirm choice of account name by typing the same account name again.
Press OK

5. Connect to Flowerpots: Make sure your Bluetooth connection is ON.
Go to My device page. Press +
Press the Light icon and you enter the New device page and the system starts searching for available Flowerpots.
6. When device code “example 0000300100038315” is shown on screen press the icon to connect. The system will now bind the Flowerpot to your account and configure the Flowerpot automatically.
7. Go back to My device page and refresh by dragging your finger down on the screen and release.
You will now see an orange icon. Orange mean you are connected. The Grey icon means you are not connected.

The device code will also be visible under Device management. You will find this, by pressing “settings” in the bottom right corner. All your available device codes will be shown here.

For saving power, device will disconnect if not used in 1 minute. The icon of device will turn grey and go into sleep mode. Reconnect by dragging your finger down on the screen and release. Once connected the icon turns orange again. If you are having trouble reconnecting, please close the app and restart.

8. To use the Light function, press the icon of the Flowerpot you want to operate.
You now enter the LUXXLight Menu
To turn on the light press the On/Off icon 
To turn of the light, press the On/Off icon

As standard colour the Flowerpot is set up for warm yellow. To activate press 

Other preset colours can be activated by pressing to colour icons



Or press any colour in the colour wheel to activate the colour you prefer

Use the slide bar icon  to set light intensity

The LUXXLight menu has following preset functions:

- **Spa Light.** Spa light therapy. Press the Spa Light icon and preset light program will start. The light changes between different colours and light intensity changes up and down in a pre-programmed pattern.
- **Sunrise.** Press the Sunrise icon and the preset light program will start. Light intensity starts from lowest intensity and within 30 minutes increases to maximum light intensity.
- **Breathing.** Press the Breathing icon and the preset light program will start. Light changes between lowest intensity and maximum intensity over and over again.
- **Random.** Press the Random icon and the preset light program starts. Colours and intensity changes randomly.

- **Timer.** In the Timer function you can program On/Off time for all light function of the App such as Spa Light, Sunrise, Breathing, Random or just any colour and intensity you prefer.

To program timer function press Timer icon and +
Set requested time. Choose if only once or every weekday on the sliding bar.
Press Set up to enter Light menu. Chose colour, intensity or one of the preset programs and press Done. You will now again see the time you set. Press Done.
In the Timer menu the On time is now displayed. To enter Off time press +
Enter Off time and press Set up.
In Set up menu press Off icon (Icon turn grey when in Off mode) Press Done
You will now again see the time you set. Press Done.
In the Timer menu the Off time is now displayed.
Maximum 5 sets of timer.

9. Speaker function

If your Flowerpot has the speaker function you can activate speaker by pressing the Play icon.
You will hear a sound from your Flowerpot when speaker is activated.

The Play icon activates the wireless function in the Flowerpot and you can now go to your Phones Bluetooth setting page where you will find the LUXX speaker in the listed available connections.

Press the LUXX speaker to connect. Once connected the connection will be programmed into the Flowerpot and Phone and you don't need to do this step again unless you disconnect for some reason. If so do the same steps again to reconnect.

The function of the Play icon is to activate the wireless unit in the Flowerpot. The wireless unit consumes a lot of energy so remember to disconnect from the speaker after use. Do so by pressing the II icon. This deactivates the wireless function in the Flowerpot.

After connecting to your phone to the Flowerpot you can play music from any of your favorite music sources or directly from your phone.

If speaker is activated by other users without the NORDIC D'LUXX app can connect to the speaker, simply by going to their Bluetooth settings in their phone and connect to the speaker. All other user must be disconnected from the speaker in order for new user to connect.

You can also connect to the speaker by pressing the On button under the base of the Flowerpot. This activates the Bluetooth chip in the Flowerpot and you can now connect via Bluetooth settings in your phone.

- ## 10. Naming your Flowerpots.
- You can name your Flowerpots in the menu of each Flowerpot. Press the wheel in the upper right corner. Press "name" and write the name you want to give the device. Press "done".
- ## 11. Light groups.
- You can make your own light groups with two or more Flowerpots in the menu under My devices. Press the + icon and hereafter Light group. Now a new

group has been created under My Device called “New group”. Press the icon and hereafter on the wheel in the upper right corner. Press “Lights” and choose which devices you want to associate in the group. After that, the selected devices are controlled via the app together.

12. Log out. Go to settings.

Press Quit. The system will keep the preset account name and just logout.

Erase password and quit. The system will erase the preset LUXX account and logout.

13. Forgot your account name? Delete account and start over.

Press and hold for 10 seconds the On/Off key under the base of the Flowerpot.

This deletes all accounts and you can now create a new account to the Flowerpot starting with instruction number 5 and onwards.

14. Trouble shooting.

If the Flowerpot does not work properly, either after installing, normal use, or in any other way then press and hold for 10 seconds the On/Off key under the base of the Flowerpot. This delete the connection from the Flowerpot to an account and you can now create a new account to the Flowerpot or reconnect to an existing account starting with instruction number 5 and onwards.

IMPORTANT NOTICE: When using battery only and battery totally run out of power you need to charge the battery as specified hereafter before use in order not to decrease the lifetime of the battery.

Flowerpot size M with light 2 hours with speaker 2 hours

Flowerpot size L with light 3 hours with speaker 6 hours

Flowerpot size XL with light 3 hours with speaker 6 hours

The Flowerpots can be used by multiple users from the same account. In order to get control of the Flowerpot last person in control of the Flowerpot must log out before other user can access the Flowerpot.

15. In order to delete a Flowerpot from an account go to Settings page and press Devise management.

Locate the Flowerpot you want to delete from the account and slide to the left. Press Delete.

DISPOSAL



Batteries, electrical and electronic equipment (EEE) contain materials, parts and substances, which can be dangerous to the environment and harmful to human health if waste of electrical and electronic equipment (WEEE) are not disposed of correctly.

Batteries, electrical and electronic equipment, which are marked with the WEEE logo (as shown on left) should not be thrown away with your household waste. Contact your Local Authority Waste Disposal Department, as they will be able to provide details of the recycling options available in your area.



Battery Safety:

Do not burn. Risk of explosion.

Do not recharge non-recharge-able batteries.

If swallowed seek immediately medical advice.

Ensure correct polarity.

If not used for extended period remove battery.



The Packaging material is partly recyclable. Dispose of the packaging in an environmentally friendly way by bringing it to a public collection centre.

NORDIC D'LUXX[®]

FLOWERPOT

Input: 5V, 5W-10W



NORDIC D'LUXX
Volmersgade 6
DK-7100 Vejle
www.nordicdluxx.dk
info@nordicdluxx.dk

Made in PRC. Batch number 608285